

CRUZETAS		COMPONENTES				
Spicer	Stahl	FLANGE DE ORELHA	GARFOS	LUVAS	PONTEIRAS	TERMINAL YOKE
5-153 X	CZ-121 CZ-225	SF-13 / SF-27 / SF-28 SF-29 / SF-31 / SF-45 SF-47 / SF-51	SG-19 / SG-28	SL-07 SL-37	SP-07 SP-37	ST-07 / ST-08 / ST-09 ST-10 / ST-11
5-160 X	CZ-210 CZ-281	SF-16 / SF-20 / SF-36 SF-37 / SF-38 / SF-52	SG-23 / SG-24	SL-08 / SL-09 / SL-23 SL-24	SP-08 / SP-09 / SP-23 / SP-23 A / SP-24 / SP-35	ST-39 / ST-40
5-165 X	CZ-221	SF-15	SG-41	SL-29	SP-28	-
5-178 X	CZ-208	SF-41	SG-31 / SG-32	SL-25	SP-25	-
5-263 X	CZ-254	SF-30 / SF-39	SG-15	SL-22	SP-22 / SP-35	ST-15 / ST-19 / ST-20 ST-21 / ST-31 / ST-35
5-273 X	CZ-252	SF-12 / SF-48	SG-14 / SG-38 / SG-42	SL-05 SL-43	SP-05 Câmbio	ST-06
5-275 X	CZ-256	SF-32 / SF-40	SG-16 / SG-30	SL-26 SL-27	SP-11 / SP-16 / SP-26 / SP-27 / SP-35	ST-02 / ST-14 / ST-16 ST-17 / ST-18 / ST-26
5-279 X	CZ-124	-	SG-17	SL-14	SP-14 / SP-14 A	ST-01 / ST-43
5-280 X	CZ-273	-	SG-27	SL-34	SP-34 / SP-34 A	ST-44 / ST-45
5-281 X	CZ-270	SF-01 / SF-34	SG-01 / SG-34	SL-04	SP-04 / SP-04 A / SP-04 B	-
5-310 X	CZ-120 CZ-253	SF-35	SG-02 / SG-29	SL-36 SL-38	SP-36 Câmbio	-
5-438 X	CZ-264	-	SG-17	SL-14	SP-12 / SP-14 / SP-14 A	ST-03 / ST-03A / ST-13 ST-13A / ST-22 / ST-23 ST-28 / ST-34 / ST-41 / ST-42
5-510 X	CZ-272	-	SG-34	SL-04	SP-04 / SP-04 A / SP-04 B SP-41 / SP-42	ST-32 / ST-49 / ST-50 ST-53
5-515 X	CZ-274	-	SG-27	SL-34	SP-34 / SP-34 A / SP-29 SP-29 A	ST-04 / ST-29 / ST-46 ST-51
5-12062 X	CZ-265	SF-03 / SF-04 / SF-09	SG-07 / SG-09	SL-20 (Adaptação) SL-39 (Adaptação)	SP-18 / SP-19 / SP-20 / SP-39 / SP-40	ST-59 / ST-64
5-12072 X	CZ-277	-	SG-03 / SG-35	SL-11 (Luveira) SL-33	SP-01 / SP-02 / SP-03	ST-60 / ST-61 / ST-62 ST-63
5-12100 X	CZ-228	SF-08	SG-12	SL-18	SP-18	-
5-12213 X	CZ-227	SF-11 / SF-19 / SF-21	SG-11 / SG-18	SL-06 SL-17	SP-06 SP-17	-
5-12219 X	CZ-229 CZ-279	SF-05 / SF-10	SG-05	SL-13 (Luveira) SL-30 (Adaptação)	SP-18	-
5-12276 X	CZ-251	-	SG-33	SL-28	SP-28	-
5-12278 X	CZ-255	SF-14 / SF-17 / SF-18	SG-08	SL-19 SL-21 (Adaptação)	SP-19 / SP-20 SP-18	ST-56 / ST-57 / ST-58
5-12924 X	CZ-230	SF-06 / SF-07 / SF-23	SG-04 / SG-10	SL-02 / SL-03	SP-01 / SP-02 / SP-03	-
5-12932 X	CZ-231	SF-02 / SF-42	SG-20	SL-16 (Luveira)	SP-04	-
SPL 90	CZ-271	-	SG-21	SL-15 SL-41 (Adaptação)	SP-15 / SP-16 SP-14	ST-05 / ST-05A / ST-12 ST-12A / ST-24 / ST-25 ST-27 / ST-37 / ST-38 / ST-52
SPL 140	CZ-290	SF-33	SG-26	-	-	ST-30 / ST-33
SPL 170	CZ-284	SF-24 / SF-26 / SF-43	SG-06 / SG-36	SL-12 (Luveira) SL-40 (Adaptação)	SP-01 / SP-02 / SP-03	-
SPL 250	CZ-232	SF-25	SG-22	SL-32	SP-04	ST-47 / ST-48
-	CZ 170	SF-46	SG-37	SL-01 / SL-42	Câmbio	-
-	CZ 280	-	SG-25	SL-35 (Adaptação)	SP-04 / SP-04 A / SP-04 B	-
-	CZ 286	SF-22 / SF-44	SG-13	SL-10 (Luveira)	SP-01 / SP-02 / SP-03	-
5-2 X	CZ-122	SF-53	SG-43	-	-	-