

CRUZETAS	COMPONENTES				
	FLANGE DE ORELHA	GARFOS	LUVAS	PONTEIRAS	TERMINAL YOKE
5-153X	SF-13 / SF-27 / SF-28 / SF-29 SF-31 / SF-45 / SF-47 / SF-51 SF-54 / SF-55	SG-19 / SG-28	SL-07 SL-37	SP-07 SP-37	ST-07 / ST-08 / ST-09 ST-10 / ST-11 / ST-65
5-160X	SF-16 / SF-20 / SF-36 SF-37 / SF-38 / SF-52 SF- 56	SG-23 / SG-24	SL-08 / SL-09 / SL-23 SL 24 / SL-44	SP-08 / SP-09 / SP-23 SP- 23 A / SP-24 / SP-35	ST-39 / ST-40
5-165X	SF-15	SG-41	SL-29	SP-28	-
5-178X	SF-41	SG-31 / SG-32	SL-25	SP-25	-
5-2X	SF-53	SG-43	-	-	-
5-263X	SF-30 / SF-39 / SF-57	SG-15	SL-22	SP-22 / SP-35	ST-15 / ST-19 / ST-20 ST-21 / ST-31 / ST-35
5-273X	SF-12 / SF-48 / SF-60	SG-14 / SG-38 / SG-42	SL-05 SL-43	SP-05 Câmbio	ST-06
5-275X	SF-32 / SF-40	SG-16 / SG-30	SL-26 SL-27	SP-11 / SP-16 / SP-26 SP- 26A / SP-27 / SP-35	ST-02 / ST-14 / ST-16 ST-17 / ST-18 / ST-26 ST- 66
5-279X	-	SG-17	SL-14	SP-14 / SP-14A	ST-01 / ST-43
5-280X	-	SG-27	SL-34	SP-34 / SP-34A	ST-44 / ST-45
5-281X	SF-01 / SF-34	SG-01 / SG-34	SL-04	SP-04 / SP-04A / SP-04B	-
5-310X	SF-35	SG-02 / SG-29	SL-36 SL-38	SP-36 Câmbio	-
5-438X	-	SG-17 / SG-45	SL-14	SP-12 / SP-12A SP-14 / SP-14A	ST-03 / ST-03A / ST-13 ST- 13A / ST-22 / ST-23 ST-28 / ST-34 / ST-41 / ST-42
5-510X	-	SG-34	SL-04	SP-04 / SP-04A / SP-04B SP-41 / SP-42	ST-32 / ST-49 / ST-50 ST-53 / ST-55
5-515X	-	SG-27 / SG-44	SL-34	SP-34 / SP-34A / SP-29 SP- 29A	ST-04 / ST-29 / ST-46 ST- 51 / ST-54 / ST-68
5-12062X	SF-03 / SF-04 / SF-09	SG-07 / SG-09	SL-20 (Adaptação) SL-39 (Adaptação)	SP-18 / SP-19 / SP-19A SP- 39 / SP-40	ST-59 / ST-64
5-12072X	-	SG-03 / SG-35	SL-11 (Luveira) SL-33	SP-01 / SP-02 / SP-03	ST-60 / ST-61 / ST-62 ST- 63
5-12100X	SF-08 / SF-59	SG-12	SL-18	SP-18	-
5-12213X	SF-11 / SF-19 / SF-21 SF- 58	SG-11 / SG-18	SL-06 SL-17	SP-06 SP-17	-
5-12219X	SF-05 / SF-10	SG-05	SL-13 (Luveira) SL-30 (Adaptação)	SP-18	-
5-12276X	-	SG-33	SL-28	SP-28	-
5-12278X	SF-14 / SF-17 / SF-18	SG-08	SL-19 SL-21 (Adaptação)	SP-19 / SP-19A SP-18	ST-56 / ST-57 / ST-58
5-12924X	SF-06 / SF-07 / SF-23	SG-04 / SG-10	SL-02 / SL-03	SP-01 / SP-02 / SP-03	-
5-12932X	SF-02 / SF-42	SG-20	SL-16 (Luveira)	SP-04	-
Ø 52,00 mm	SF-49	SG-39	-	-	-
Ø 59,00 mm	SF-50	SG-40	-	-	-
SPL90	-	SG-21	SL-15 SL-41 (Adaptação)	SP-15 / SP-15A SP-14 / SP-14A	ST-05 / ST-05A / ST-12 / ST-12A ST-24 / ST-25 / ST-27 ST-37 ST- 38 / ST-52 / ST-74
SPL140	SF-33	SG-26	-	-	ST-30 / ST-33 / ST-69 ST- 70 / ST-71 / ST-72 ST-73
SPL170	SF-24 / SF-26 / SF-43	SG-06 / SG-36	SL-12 (Luveira) SL-40 (Adaptação)	SP-01 / SP-02 / SP-03	-
SPL250	SF-25	SG-22	SL-32	SP-04	ST-47 / ST-48 / ST-67
CZ-170	SF-46	SG-37	SL-01 / SL-42	Câmbio	-
CZ-280	-	SG-25	SL-35 (Adaptação)	SP-04 / SP-04A / SP-04B	-
CZ-286	SF-22 / SF-44	SG-13	SL-10 (Luveira)	SP-01 / SP-02 / SP-03	-