

CRUZETAS		COMPONENTES				
Spicer	Stahl	FLANGE DE ORELHA	GARFOS	LUVAS	PONTEIRAS DESLIZANTE	TERMINAL YOKE
5-153X	CZ-121 CZ-225	SF-13 / SF-27 / SF-28 / SF-29 / SF-31 / SF-45 / SF-47 / SF-51 / SF-54 / SF-55 / SF-63 / SF-64 / SF-68 / SF-69 / SF-70	SG-19 / SG-28 / SG-48	SL-07 / SL-37 / SL-45 / SL-46 SL-47	SP-07 / SP-37 / SP-45	ST-07 / ST-08 / ST-09 ST-10 / ST-11 / ST-65
5-160X	CZ-210 CZ-281	SF-16 / SF-20 / SF-36 SF-37 / SF-38 / SF-52 / SF-56 / SF-61 / SF-62	SG-23 / SG-24	SL-08 / SL-09 / SL-23 SL-24 / SL-44 / SLE-16	SP-08 / SP-09 / SP-23 / SP-24	ST-39 / ST-40
5-165X	CZ-221	SF-15	SG-41	SL-29	SP-28 / SP-28A / SP-44	-
5-178X	CZ-208	SF-41	SG-31 / SG-32	SL-25	SP-25	-
5-263X	CZ-254	SF-30 / SF-39 / SF-57	SG-15 SG-50	SL-22 SL-50	SP-21 / SP-22 SP-50	ST-15 / ST-19 / ST-20 / ST-21 ST-31 / ST-35
SPL55	-	SF-30 / SF-39 / SF-57	SG-15 SG-50	SL-22 SL-50	SP-21 / SP-22 SP-50	ST-15 / ST-19 / ST-20 / ST-21 ST-31 / ST-35
5-273X	CZ-252	SF-12 / SF-48 / SF-60 / SF-66 SF-67 / SF-68	SG-14 / SG-38 / SG-42	SL-05 / SL-49 SL-43	SP-05 / SP-05A / SP-10 / SP-48 Câmbio	ST-06
5-275X	CZ-256 CZ-114	SF-32 / SF-40	SG-16 / SG-30	SL-26 SL-27	SP-26 / SP-27 SP-11	ST-02 / ST-14 / ST-16 / ST-17 ST-18 / ST-26 / ST-66
SPL70	-	SF-32 / SF-40	SG-16 / SG-30	SL-26 SL-27	SP-26 / SP-27 SP-11	ST-02 / ST-14 / ST-16 / ST-17 ST-18 / ST-26
5-279X	CZ-124	-	SG-17	SL-14	SP-14 / SP-14A	ST-01 / ST-43
5-280X	CZ-273	-	SG-27	SL-34	SP-34 / SP-34A	ST-44 / ST-45
5-281X	CZ-270	SF-01 / SF-34	SG-01 / SG-34	SL-04	SP-04 / SP-04A / SP-04B	-
5-310X	CZ-120 CZ-253	SF-35	SG-02 / SG-29	SL-36 SL-38	SP-36 Câmbio	-
5-438X	CZ-264	-	SG-17 / SG-45	SL-14	SP-14 / SP-14A	ST-03 / ST-03A / ST-13 ST-13A / ST-22 / ST-23 / ST-28 ST-34 / ST-41 / ST-42
5-510X	CZ-272	-	SG-34	SL-04	SP-04 / SP-04A / SP-04B	ST-32 / ST-49 / ST-50 / ST-53 ST-55
5-515X	CZ-274	-	SG-27 / SG-44	SL-34	SP-34 / SP-34A	ST-04 / ST-29 / ST-46 / ST-51 ST-54 / ST-68
5-12062X	CZ-265	SF-03 / SF-04 / SF-09	SG-07 / SG-09	SL-20 (Adaptação) SL-39 (Adaptação)	SP-18 SP-19 / SP-19A	ST-59 / ST-64
5-12072X	CZ-277	-	SG-03 / SG-35 / SG-46	SL-11 (Luveira) SL-33	SP-01 / SP-02 / SP-03	ST-60 / ST-61 / ST-62 / ST-63
5-12100X	CZ-228	SF-08	SG-12	SL-18	SP-18	-
5-12213X	CZ-227	SF-11 / SF-19 / SF-21	SG-11 SG-18	SL-06 SL-17	SP-06 SP-17	-
5-12219X	CZ-229 CZ-279	SF-05 / SF-10	SG-05	SL-13 (Luveira) SL-30 (Adaptação)	SP-18	-
5-12276X	CZ-251	-	SG-33	SL-28	SP-28 / SP-28A / SP-44	-
5-12278X	CZ-255	SF-14 / SF-17 / SF-18	SG-08	SL-19 SL-21 (Adaptação)	SP-19 / SP-19A SP-18	ST-56 / ST-57 / ST-58
5-12924X	CZ-230	SF-06 / SF-07 / SF-23	SG-04 / SG-10	SL-02 / SL-03	SP-01 / SP-02 / SP-03	-
5-12932X	CZ-231	SF-02 / SF-42	SG-20	SL-16 (Luveira)	SP-04 / SP-04A / SP-04B	-
Ø 52,00	CZ-203	SF-49	SG-39 / SG-47	SL-48	SP-47	-
Ø 59,00	CZ-214	SF-50	SG-40 / SG-47	SL-48	SP-47	-
SPL90	CZ-271	-	SG-21	SL-15 SL-41 (Adaptação)	SP-15 / SP-15A SP-14 / SP-14A	ST-05 / ST-05A / ST-12 / ST-12A / ST-24 / ST-25 / ST-27 ST-37 / ST-38 / ST-52 / ST-74 / ST-75
SPL140	CZ-290	SF-33	SG-26	-	-	ST-30 / ST-33 / ST-69 / ST-70 ST-71 / ST-72 / ST-73
SPL170	CZ-284	SF-24 / SF-26 / SF-43	SG-06 / SG-36	SL-12 (Luveira) SL-40 (Adaptação)	SP-01 / SP-02 / SP-03	-
SPL250	CZ-232	SF-25	SG-22	SL-32	SP-04	ST-47 / ST-48 / ST-67
-	CZ-170	SF-46	SG-37	SL-01 / SL-42	Câmbio	-
-	CZ-280	-	SG-25	SL-35 (Adaptação)	SP-04 / SP-04A / SP-04B	-
-	CZ-286	SF-22 / SF-44	SG-13	SL-10 (Luveira)	SP-01 / SP-02 / SP-03	-
5-2X	CZ-122	SF-53	SG-43	SLE-15	SP-36	-